

Trash Bin

911

Kit Contents:

4-5/8" flat screws
8-1-5/8" screws
7-1-1/4" screws
2- Side Panels w/predrilled holes
2- Side Panels without predrilled holes
1-Lid w/hinges
1-Handle w/screws
1 Flip sign/Soil & Trash



Step 1: Place one side panel without the predrilled holes on end with the cleats facing in. Then place one panel with the predrilled holes up against the first so that the outside edge fits up against the cleat of the first panel. (see photo #2) Insert 1-5/8" screws into the predrilled holes on the outside of the panel top and bottom.

Step 2: Repeat with the next two panels to make a square.




Photo #2

Step 3: Drop the lid onto the top of the unit with the hinges hanging over the back of the unit. It will fit only one way. Attach the hinges to the back using the 1-1/4" screws.

Step 4: Lift the lid to the open position, pulling the chain tight. While holding the lid open, attach the chain to the unit with one 1-1/4" screw.

Step 5: Attach the handle to the front of the lid using the two 5/8" flat head screws. See top photo.

Step 6: Attach the sign to the front of the bin by inserting 2-5/8" flat screws into the pre-drilled holes of the sign and tightening them into the bin front.



For questions or ordering information contact
The Maine Bucket Company's customer service at 1-800-231-7072
www.mainebucket.com